

ACTI WASH



Resin Bound Rubber (Wet Pour) Treatment Guide

Equipment

- **Chemical applicator** (e.g., knapsack, hand sprayer, mechanical sprayer, watering can etc.)
- **Brush** (e.g., yard brush, Vikan cleaning brush etc.) If available, a specialised ground sweeper will help to facilitate the efficient removal of loose material on mass.

Contingent on the individual case, some of the above equipment may not be necessary.

Preparation

Remove all weeds from the resin bound rubber area. Clean all loose soiling (mud) with water and a suitable detergent if necessary. Ensure the resin bound rubber surface is free from fallen leaves.

Dilution of the Concentrate

Version	Dilution Ratios	
	Mild Treatment	Heavy Treatment
Actiwash Pro	40:1	35:1
Actiwash Domestic	12:1	10:1

Application

Application - without moss present. Prepare a diluted solution of Actiwash in the tank of the chemical application equipment. Saturate the resin bound rubber surface with the prepared solution by spray or pour, then leave.

Application - with moss present. Prepare a diluted solution of Actiwash in the tank of the chemical application equipment. Saturate the resin bound rubber surface with the prepared solution by spray or pour, then leave. Once the moss has changed colour and turned orange (usually within two weeks), the roots of the deposits will begin to decompose and can then be swept up with a yard brush (or mechanical sweeper). Apply a final saturation of the Actiwash solution to the resin bound rubber surface. This ensures a thorough treatment and will help to keep the resin bound rubber surface free from the formation of naturally occurring contamination.

Post-treatment

The biofilm dies shortly after saturation with Actiwash while the resin bound rubber is drying. Afterwards, the processes of natural weathering takes control to clean away the staining. Each organic stain will eventually disappear, with some diminishing quickly and others taking more time. For example, green staining will disappear within a week. Red staining will take 1-2 weeks. Black/dark

Continued.

ACTI WASH



Resin Bound Rubber (Wet Pour) Treatment Guide

staining can take several months to disappear; however, lightening of the contamination should be noticeable within the first few weeks and months following treatment. Yellow and white spots (lichens) can often be the final contaminant remaining to be weathered away. The crust will dry out and recede. Rain and freeze-thaw weather cycles are beneficial.

FAQ

Q When should I apply Actiwash?

A Apply onto a dry substrate in temperatures above 7 degrees Celsius when rain is not expected for at least a few hours post-treatment. Ensure the surface stays 'wet' for 30 minutes after treating with Actiwash. Avoid applying onto very hot surfaces as the solution may evaporate too quickly.

Q How should I protect nearby plants and grass during treatment?

A Water nearby plants and grass before and after surface treatment. Lightly cover vegetation which may be exposed to a greater risk of over-spray/runoff.

Q When can a play area be used again after treating?

A The play area can be used once the substrate is completely dry following the first rainfall if children will be playing.

Q How much Actiwash solution is used per metre squared?

A 1 litre of diluted solution should treat approximately 2 metres squared. Actual consumption may vary depending on the porosity of the substrate being treated.

Q What is a biofilm?

A A biofilm is a structured community of microorganisms that adhere to surfaces and can include bacteria, fungi, algae, and protozoa.

Q I'm finding the orange deposits difficult to sweep up. What can I do?

A Some deposits have well established root structures and may require additional time to decompose after treatment in order to be easily swept up.